



Threaded tee

Transair	ØD (in)	L	LI	ZI	Z2
RR26 H3N04 01	1/2	42.1	30	11.7	13.7
RR26 H5N06 01	3/4	56	32.8	14.5	16.2

Transair	ØD (in)	C (in)	L	ZI	Z2
RX20 L1N04	3	1/2	290	145	63
RX20 L3N04	4	1/2	310	155	75.8

Use two connectors RR01 to connect threaded tee RX23 to Ø 3'' or Ø 4'' Transair pipe.

Plug-in reducer

Transair	ØDI (in)	ØD2 (in)	L	Z
RR06 H5 H3 01	3/4	1/2	73.2	3.2

Transair	ØDI (in)	ØD2 (in)	L
RR65 M4N06	1 1/2	3/4	140
RR65 M6N06	2	3/4	150

Transair	ØDI (in)	ØD2 (in)	L
RX66 M6 M4	2	1 1/2	220
RX66 L1 M6	3	2	240
RX66 L3 L1	4	3	192

Use connector RR01 to connect plug-in reducer RX66 to Transair pipes Ø 3'' or Ø 4'' and pipe-to-pipe connector RP06 to connect to Transair pipe Ø 2''.